



**P365 Threaded Barrel and Compensator
 Installation Instructions**



1. Threaded Barrel and Compensator
2. 2x 6-32 Set Screws
3. 1/16" Drive Allen Key
4. 263 Red Loctite®
5. 242 Blue Loctite®

Step 1: Field Strip

Field strip your P365 by rotating the takedown lever counterclockwise and releasing the slide forward as shown.



Step 2: Barrel Disassembly

Remove the guide rod assembly by pulling it out, and then remove the barrel from the slide at a 45-degree angle for ease.



Step 3: M*CARBO Barrel Assembly

Reassemble the M*CARBO barrel and guide rod assembly by reversing the disassembly process. Since the barrel is longer than factory, gently maneuver it into the slide opening until it is properly seated and correctly positioned. Assemble the recoil assembly as shown.



Step 5: Screw in Compensator

Screw in the compensator clockwise until it meets a firm stop provided by the slide.



Step 4: Red Loctite 263 Application

Apply a moderate quantity of red Loctite to the tip of the threads. The act of threading the compensator onto the barrel will distribute the thread locker uniformly along the thread.



Step 6: Align compensator with Slide

Unscrew the compensator counter-clockwise until it is aligned vertically as depicted in the image. It is imperative to perform steps 4 and 5 within 2-3 mins, as the red Loctite will solidify rapidly. Verify that there is a slight clearance between the compensator and the slide.



Step 7: Position Set Screws

Orient the set screws by threading them in at a 45-degree angle, as illustrated in the figure. Insert only a single thread, leaving most of the threads visible.



Step 8: Apply Blue Loctite, Tighten Set Screws

Apply a moderate quantity of blue Loctite to both set screws. Secure the screws firmly, adhering to a torque specification of **20 inch-pounds**. Use a clean cloth to wipe away any excess Loctite.



Step 9: Check for Operation

Verify the installation's accuracy by racking the slide back and forth. Should the compensator be properly aligned, the slide will function as it did prior to the installation. Wait 24 hours for full curing before taking it to the range.



You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

(P.) (727) 223-1816 (E.) help@mcabo.com